

K00127 ADAPTER KIT

Installation Instructions

- 1. The K00127 adapter kit is used for installing a B-0450, B-0600, B-1000, J-0450, J-0600, J-0800, or J-1000 ice machine on a C-0970 bin. The bin must be leveled before proceeding to step 2.
- 2. Installation of Adapter (see illustration):
 - A. Locate right-hand and left-hand adapter panels.
 - B. Using the adapter panels as templates, drill four 5/32" diameter holes for each adapter in bin.
 - C. Fasten panels in place with the screws provided in kit.
 - D. Apply foam tape, as shown.
- 3. Installation of Ice Machine:
 - A. Position ice machine on bin.
 - B. Proceed to ice machine installation instructions for electrical and water hook-up and start-up procedure.